

1. Connect the **power supply** to the back of your **label printer**.



2. Connect the **power cord** to the power supply and an electrical outlet.



3. Connect one end of the **USB cable** to your label printer.



4. Connect the other end of the **USB cable** to your computer.



5. Turn on your label printer.



Insert a label roll

To insert a label roll:

- 1. Pull the yellow **latches** on both sides of the printer towards you and lift the printer's **lid** open.
- 2. Pull the yellow **roll guides** apart and insert the **label roll** with the labels facing upwards.
- 3. Release the **roll guides** and push them together. Make sure the **label roll** is secure and turning freely.



4. Pull the **labels** out past the cutter at the front of the printer.

5. Push the **labels** under the roll guides.



6. Flip the **labels** up and align the **movable sensor** to the centre position.



7. Push the lid closed until both yellow latches snap shut.



Add your printer to your computer and configure for ICE Printing

The steps you need to follow to add your printer to your computer depend on its operating system, your admin level and if the printer drivers are installed. Before you continue, make sure your computer is connected to a USB port on your computer and that it's powered on, you have sufficient rights to install printers and printer drivers, and rights to install ScriptX (Administrator rights)

1. Select Start menu > Control Panel.

Scree	Programs and Features					
2016-	Power Options					
	Event Viewer					
	System					
	Device Manager					
	Network Connections					
	Disk Management					
	Computer Management					
	Command Prompt					
	Command Prompt (Admin)					
	Task Manager					
	Control Panel					
	File Explorer					
	Search					
	Run					
	Shut down or sign out					
	Desktop					
	O Ask me anything	ļ,	[]]	e	-	Ŧ

Note: If your computer is running Windows 8 or 10, right-click the **Start menu** instead of doing a left-click.

2. Under Hardware and Sound, select View devices and printers.



3. Under *Printers*, right-click your **Zebra ZD410** and select **Printer preferences**. Its default name will be *ZDesigner ZD410-203dpi ZPL*, **this MUST be changed to ICE Label Printer**.

If your printer hasn't shown up, and has been connected correctly and is powered on, you may need the printer drivers installed. The latest drivers are available on the Zebra website:

https://www.zebra.com/gb/en/support-downloads/printers/desktop/zd410.html



4. In the Page Setup submenu, Change Media Type to "Labels with Black Marks"

Page Setup	Stock Select	Cuttor v	Point preview	
Operation Mode Operation Mode Graphic Options Custom Commands Maintenance Units Help and About	Media settings Illidit: Hegist Media tope Risation: Mark offue Differentiabil Invente	Stimm (* 20 50 Smm (* 20 Labels with black marks (* 17 0 * Polstat (* 17 0 cm (* 20)	123	
Phint text page CEBRA Decision for another Decision for another				

In the Print Options submenu, Change Printing Mode to "Direct Thermal"

ê K	E Label Printer Printing Pre	ferences	3	¢
Printe	r Settings			
D	Page Setup	Print settings	Print preview	
•	Print Options	Speed:	152 mm/s v	
	Operation Mode	Printing mode:	Dectremal Dect	
	Graphic Options	Offsets	100	
08	Custom Commands	Top:	123 123	
*	Maintenance	Advanced settings		
L	Units	Backfeed:	Delast v 👩 🗤 🗤 👘 🖓	
1	Help and About	Paule	No pause v	
		Control characters:	Standard v	
_		RTC mode:	Stat print time v	
1	Print test page	Cancel all curren	rt and queued printing documents	
	di TERRA	Passthrough		
	ALC TERKY	Enable passitivo	ugh mode	
	abraCesigner Essentials	Stat sequence:	8	
			OK Cancel Apply Help	í

- 5. Select OK.
- 6. Close the *Devices and Printers* window.

Calibrate your printer

For your label printer to recognize the size of your labels, you need to calibrate it. This will make sure that your labels will print correctly. To do so, hold down the **pause** and **cancel** buttons for two seconds and release. The printer will measure and feed a few blank labels.



Note: Calibrating your label printer is only necessary when you insert a new label roll of a different size. If you insert a new label roll of the same size, your printer will remember the settings from the calibration you did with the initial label roll. You can also quickly press the **feed** button (middle button) twice before printing. This will make sure that they're correctly aligned and ready to print.

Your Zebra ZD410 label printer should now be set up for custom label printing.

Installing ScriptX for ICE Printing

The ScriptX software ensures that your ICE label requests are directed to your new ICE Label Printer, whether it is your default printer or not.

ScriptX is supplied by MeadCo and is available on the following website:

https://scriptx.meadroid.com/download/user-upgrade-to-current-version.aspx

To install ScriptX launch the download file (this will need administrator rights on the pc)

Accept the agreement and select Install

🛃 MeadCo ScriptX (v8.3.0.	4 (x86)) Setup	-	
-	Please read the Mea License Agreement	adCo ScriptX (v8.:	3.0.4 (x86))
	SOFTWARE LICENSE ScriptX MEADCO SOFTWARE	E FOR:	^
	IMPORTANT - REA	D CAREFULLY:	
	This MeadCo End Us ("EULA") is a legal a (either an individual & Co Limited for the identified above, wh software and associa materials, and may documentation ("SO "SOFTWARE"). By in otherwise using the	er License Agreem greement between or a single entity) MeadCo software ich includes compu ated media and pri include "online" or FTWARE PRODUCT stalling, copying, o SOFTWARE PRODU	ent you and Mead product ter nted electronic " or r ICT, you_ ¥
	I accept the terms in	the License Agreemen	t

Was this article helpful? <u>mailto:GHNT.PathSupport@nhs.net?subject=ICE Printer</u> <u>Installation</u>

<u>Submit a</u> <u>request</u>